

Industrial 10/100M Ethernet to Fiber Optic Converter Part Number: FBR-Ethernet-2 (DIN-Rail/Wall-Mount)

Single-Mode (12.4miles/20km) or Multi-Mode (1.2miles/2km)

Connector types: ST, SC or FC





Http://www.CommFront.com

Industrial 10/100M Ethernet to Fiber Optic Converter

Part Number: FBR-Ethernet-2 (DIN-Rail/Wall-Mount)



■ INTRODUCTION

The FBR-Ethernet-2 (DIN-Rail/Wall-Mount) is a rugged, industrial-grade 10/100M Ethernet to fiber optic media converter, which provides one channel for media conversion between 10/100BaseTX and 100BaseFX fiber optic links. Depending on the fiber cable and the type of media converter used, a multi-mode media converter can extend the 10/100M Ethernet distance to up to 1.2 miles (2 km), while a single-mode media converter can extend the distance to up to 12.4 miles (20 km). The FRB-Ethernet-2 is a plug and play unit featuring auto-negotiation for half or full-duplex and 10 or 100Mbps data rates, it also supports MDI (straight-through) and MDIX (crossover) cables, no DIP switch or jumper settings are required.

■ FEATURES

- Enclosed in a rugged, rustless ABS housing.
- Direct DIN-Rail or wall/panel mounting without using any unsecured brackets or adapters.
- Converts 10/100BaseTX to 100BaseFX fiber optic links.
- Transmits 10/100M Ethernet data over a long distance through fiber cables (Multi-mode: 1.2 miles or 2 km; Single-mode: 12.4 miles or 20 km).
- Auto-negotiation of speed and duplex mode on TX port.
- Auto-MDIX on TX port.
- Store-and-forward mechanism.
- · LED indications.
- Single or Multi-mode, with ST, SC or FC connectors.
- A wide range of fiber optic cables is supported.
- Built-in surge protection, static protection and circuit protection.
- Surface Mount Technology manufactured to RoHS and ISO-9001 standards.
- Safety: Strictly certified by TUV (Cert No. SG-CE-100005; SG-FCC-100002).
- 5 Year manufacturer's warranty.

■ SPECIFICATIONS


| Compatibility: | IEEE802.3 10Base-T; IEEE802.3u 100Base-TX and 100Base-FX | | |
|---------------------------------|---|--|--|
| Power Source: | 9 to 30VDC (External AC to DC power adapter included) | | |
| External AC/DC Power Adapter: | 9VDC/500mA (Input: 100~240VAC 50/60Hz, US type A plug) | | |
| Features: | Auto-negotiation for half/full-duplex and 10/100M on TX port; | | |
| | Auto-MDIX on TX port | | |
| Switching Method: | Store-and-forward | | |
| Speed: | 10BaseT: 10/20Mbps for half/full-duplex | | |
| | 100BaseT: 100/200Mbps for half/full-duplex | | |
| Current Consumption: | Less than 200mA | | |
| Wavelength: | 1310nm | | |
| Usable Fiber Optic Cables: | Multi-mode: 50/125, 62.5/125µm | | |
| | Single-mode: 8.3/125, 8.7/125, 9/125, 10/125μm | | |
| Distance (Ethernet): | 10BaseT: Cat. 3, 4, 5 up to 328ft (100m) | | |
| | 100BaseT: Cat. 5 up to 328ft (100m) | | |
| Distance (Fiber Lines): | Multi-mode: 1.2 miles (2km); Single-mode: 12.4 miles (20km) | | |
| Connectors (Ethernet/Power): | RJ45 (Female) / Terminal Block (9-way) | | |
| Connectors (Fiber Links): | 2x ST Connector, 2x SC Connector or 2x FC Connector | | |
| Surge Protection: | 600W | | |
| Electro-Static Discharge (ESD): | Up to 15KV | | |
| Dimensions (H x W x D): | ST: 4.9 x 2.9 x 1.3 in (125 x 73 x 33 mm) | | |
| | SC: 4.7 x 2.9 x 1.3 in (120 x 73 x 33 mm) | | |
| | FC: 4.6 x 2.9 x 1.3 in (117 x 73 x 33 mm) | | |
| Weight: | ST: 4.6 oz (130 g) / SC: 4.6 oz (129 g) / FC: 4.6 oz (129g) | | |
| Operating Temperature: | -40°F to 85°F (-40°C to 85°C) | | |
| Operating Humidity: | 0 to 90% Non-condensing | | |

Revision: 1.5 www.CommFront.com Page 2 of 4

■ CONNECTIONS FBR-ETHERNET-2 FBR-ETHERNET-2 (DIN-Rail/Wall-Mount) (DIN-Rail/Wall-Mount) FIBER LINKS (2x) RX PC, HUB OR PC, HUB OR RX RX **SWITCH** SWITCH TX CAT 5E CABLE CAT 5E CABLE MULTI-MODE: 1.2 MILES (2KM) 328FT (100M) 328FT (100M) SINGLE-MODE: 12.4 MILES (20KM)

FIGURE 1: FBR-ETHERNET-2 CONNECTION DIAGRAM

■ RJ45 / TERMINAL BLOCK PIN ASSIGNMENT



| RS45 | Terminal Block |
|-------------------------|----------------|
| 1 | TX+ |
| 2 | TX- |
| 3 | RX+ |
| 6 | RX- |
| 4,5,7,8 (Not Connected) | - |

■ INSTALLATIONS




FIGURE 2: DIN-RAIL MOUNTING




FIGURE 3: WALL/PANEL MOUNTING

■ LED INDICATIONS (FRONT VIEW)




FIGURE 4: FBR-ETHERNET-2 LED INDICATIONS

■ TROUBLESHOOTING

- Make sure the Power is connected and turned on.
- Check the connections according to the above "CONNECTIONS" diagram (Figure 1).
- Check the LED status and identify the possible problems by using the table below:

| LED | State | Indication |
|-------------------------|----------|--|
| PWR (Power) | Steady | Power on |
| | Off | Power off |
| LNK/ACT (TX) | Steady | Network connected |
| (TX Port Link/Activity) | Flashing | Transmitting or receiving data |
| | Off | Network disconnected |
| LNK/ACT (FX) | Steady | Fiber links connected |
| (FX Port Link/Activity) | Flashing | Transmitting or receiving data |
| | Off | Fiber links disconnected |
| FDX | Steady | Full-duplex mode |
| | Off | Half-duplex mode or network disconnected |
| 10/100M | Steady | 100M network |
| | Off | 10M network or network disconnected |